



RAPIDFENCE™

Balmain Federation Style Fence Panel Assembly Instructions




INSTRUCTION MANUAL

Item : 100654 - BALMAIN FEDERATION STYLE FENCE PANEL/GATE
800301 - BALMAIN FEDERATION STYLE GATE

ASSEMBLY INSTRUCTIONS

BALMAIN FEDERATION STYLE FENCE PANEL/GATE



FOR FIXING AS A FENCE PANEL

- 1. Panel Placement:** Position your fence panel between the posts, leaving approximately 5mm on either side to accommodate potential panel or post movement.
- 2. Horizontal Alignment:** Once you are satisfied with the height & position of your panel, use saddle clamps to locate position on the underside of the horizontal pipe. Mark on both sides once you are confident it is perfectly level horizontally.
- 3. Vertical Alignment:** Locate the position of the bottom clamp, similar to using hinge clamps. Mark on both sides once you are confident it is perfectly level vertically.
- 4. Pre-Drill Holes:** Pre-drill holes smaller than the fixings you intend to use (M6 or M8 coach screws are suitable).
- 5. Top Bracket Fixing:** Position the panel and fix the top brackets on either side. Leave a small allowance for adjustments before the final fix.
- 6. Bottom Bracket Fixing:** Securely fix the bottom brackets. Once you confirm that the panel is level all around, tighten all fixings to finish the installation.


ASSEMBLY INSTRUCTIONS

FOR FIXING AS A GATE – TOP BRACKET

1. **Locate Gate Position:** Determine where you want the gate mounted, allowing for a space between 50 and 100mm from the ground to the underside of the gate.
2. **Backing Plate Marking:** Mark the location of the backing plate, aligning it with the underside of the top horizontal pipe.
3. **Mounting the Backing Plate:** Mount the backing plate to the post and pre-drill holes (slightly smaller than the fixings you plan to use - M6 or M8 coach screws).
4. **Strap Placement:** Place the strap on one side of the gate vertical pipe.
5. **Clamp Placement:** Place the clamp on the other side of the gate vertical pipe, directly underneath the top horizontal pipe.
6. **Fixing the Clamp:** Securely fix the clamp to the post through the clamp holes and backing plate holes.


FOR FIXING AS A GATE - BOTTOM BRACKET

1. **Backing Plate Installation:** Once you are satisfied the gate is vertically level mount the backing plate to the post and pre-drill holes (slightly smaller than the fixings you plan to use - M6 or M8 coach screws).
2. **Strap Placement:** Place the strap on one side of the gate.
3. **Clamp Placement:** Place the clamp on the other side of the gate, roughly halfway between the bottom weld point and the topside of the bottom horizontal pipe.
4. **Fixing the Clamp:** Securely fix the clamp to the post through the clamp holes and backing plate holes.



ASSEMBLY INSTRUCTIONS

BALMAIN FEDERATION STYLE GATE



FOR FIXING AS A GATE - BOTTOM BRACKET

1. Locate Gate Position: Determine where you want the gate mounted, allowing for a space between 50 and 100mm from the ground to the underside of the gate. When measuring, also allow space between posts to include the hinge and latch set you purchase.

2. Backing Plate Marking: Mark the location of the backing plate, aligning it with the underside of the top horizontal pipe.

3. Mounting the Backing Plate: Once you are satisfied the gate is vertically level mount the backing plate to the post and pre-drill holes (slightly smaller than the fixings you plan to use - M6 or M8 coach screws).

4. Strap Placement: Place the strap on one side of the gate vertical pipe.

5. Clamp Placement: Place the clamp on the other side of the gate vertical pipe, directly underneath the top horizontal pipe.

6. Fixing the Clamp: Securely fix the clamp to the post through the clamp holes and backing plate holes.

ASSEMBLY INSTRUCTIONS

FOR FIXING AS A GATE – TOP BRACKET

- 1. Backing Plate Installation:** Once you are satisfied the gate is vertically level, mount the backing plate to the post and pre-drill holes (slightly smaller than the fixings you plan to use - M6 or M8 coach screws).
- 2. Strap Placement:** Place the strap on one side of the gate.
- 3. Clamp Placement:** Place the clamp on the other side of the gate, roughly halfway between the bottom weld point and the topside of the bottom horizontal pipe.
- 4. Fixing the Clamp:** Securely fix the clamp to the post through the clamp holes and backing plate holes.

